


CONNECTION SPACE



Connection compartments are designed to house power cables and auxiliary external conductors.

It includes:

- Power and auxiliary terminals for functional units
- Auxiliary collectors
- Cable supports for cable attachment.

The emplacement of this compartment depends on front or rear access.

Rear access

In this case the compartment is located behind the column.

Front access

In this case the 400 mm width compartment is located on the right of the column.

External conductors can exit from column tops or bottoms. Separation by barriers or partitions between operational unit terminals enables insulation and isolation upgrade from form 3b to 4b.

